



Technical Guide:


Unshackling a Lock



Step 1: On the home screen, select the settings icon next to your name.



Step 2: In Settings, select 'Advanced'. Under Lock Maintenance, select 'Unshackle'.



Step 3: This will open the Unshackle Lock screen – follow the steps to unshackle.